




Manually Changing Satellite Correction Settings

EZ-Guide® 250 and EZ-Guide 500

1. From the home screen, select the **wrench** icon:
2. On the *Configuration* screen, select **System**.
3. On the *System* screen, select **GPS**.
4. On the *GPS* screen, select **GPS Setup**.
5. On the *GPS Correction Source* screen, select **WAAS / EGNOS**:



6. On the *WAAS/EGNOS Settings* screen, select **Satellite**.
7. On the *Satellite* screen, choose the desired **WAAS 135**:

