



Manually Changing Satellite Correction Settings

FM-750™

1. From the home screen, select the **Settings** wrench:



2. On the *Settings* screen, select **GNSS/GPS**.



3. On the *GNSS* screen, select **GNSS/GPS Setup**.

GPS



4. On the *GNSS Correction Source* screen, select **WAAS/EGNOS** and tap the green **Accept** button.
5. On the *WAAS/EGNOS Settings* screen, select **Satellite**.

On the *Satellite* screen, choose the desired **WAAS 135** and tap the green **Accept** button.